

Flash Memory Socket

CF Express/CFast(Compact Fast)/CF(Compact Flash)/SD/Mirco SD/Smart Card

V. 04/21



CF



101B-TAA0-R



Ejector L=20mm
101C-ESB0-R




Locating Peg: 38.74mm
101D-TAAB-R01
Locating Peg: 40.16mm
101D-TAAA-R01
Locating Peg: 38.74mm, Stand off 1.4mm
101D-TACB-R01
Locating Peg: 40.16mm, Stand off 1.4mm
101D-TACA-R01



Locating Peg: 38.74mm
101D-RAAB-R01
Locating Peg: 40.16mm
101D-RAAA-R01
Locating Peg: 38.74mm, Stand off 1.4mm
101D-RACB-R01
Locating Peg: 40.16mm, Stand off 1.4mm
101D-RACA-R01


SD




with switch
104C-TAA1



with switch
104D-RCA0-RA1



104D-TCA0-R06
Stand off 1.8mm
104D-TCC0-R06



with card lock
104H-TDA0-R01

CFexpress



Push-Push

15u"
101M-TE10



Push-Pull


15u"
101M-TE20



Push-Pull w/Lock

15u"
101M-TE30

Micro SD



Push-Push

112L-TDA0




Hinge

10u"
112C-TBAR-R02



Push-Push

with switch, H= 1.85mm
112J-T DAR-R01



Push-Push

H=1.83mm
112A-TAAR-R03

CFast



Push-Pull

H=6.05mm
120A-605D00
H=8.35mm
120A-835D00



Push-Pull

with lock, H=6.05mm
120B-605D00
with lock, H=8.35mm
120B-835D00



Push-Push

H=6.05mm
120C-605D00
H=8.35mm
120C-835D00



Slim

H=4.15mm
120D-4C00



Vertical


without lock
120E-0G00



Vertical

with lock
120E-1G00

Smart Card



Push-Pull

with switch
104C-TAA1



Push-Push

with switch
104D-RCA0-RA1